

Model YD-909-CBA

AirNmore
**COMFORT
BUDDY**



DO NOT RETURN TO STORE.

Have your receipt handy and contact our Customer Service Department at:
(888) 281-9031 or (845) 520-3002.

To ensure you get the best results from your portable heater, please read this manual before using, and keep it for future reference. For additional information, please contact your place of purchase or call 888-281-9031.

READ ALL INSTRUCTIONS BEFORE USING THIS HEATER

Important Safety Instructions

WARNING

IMPROPER USE OF THIS HEATER COULD RESULT IN RISK OF FIRE, ELECTRIC SHOCK, AND INJURY TO PERSONS:



RISK OF ELECTRICAL SHOCK.
DO NOT OPEN. NO USER SERVICEABLE PARTS INSIDE.

WARNING

ANY REQUIRED SERVICE, OTHER THAN FILTER MAINTENANCE, SHOULD BE PERFORMED ONLY BY AN AUTHORIZED SERVICE REPRESENTATIVE. ANY OTHER REPAIRS, ATTEMPTED BY ANYONE OTHER THAN AN AUTHORIZED SERVICE REPRESENTATIVE, WILL VOID THE WARRANTY.


FOR AUTHORIZED SERVICE

CALL 1-888-281-9031 OR VISIT www.airNmore.com

Model YD-909-CBA

Read all safety instructions before using this heater.


1. This heater's grill is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9m) from the front, sides and rear of the heater.
2. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
3. Always unplug heater when not in use.
4. Do not operate any heater with a damaged cord or plug, or after it has been dropped or damaged in any manner. In such cases, return the heater to an authorized service facility for inspection/repair.
5. Do not use the heater outdoors or on construction sites.
6. The heater is not intended for use in bathrooms, laundry areas and similar indoor locations, areas with standing water, a shower or swimming pool. Never place the heater where it may fall into a bathtub or other water container.
7. Do not run the cord under carpeting. Do not cover the cord with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas and where it will be tripped over.
8. To disconnect the heater, turn the unit off, then remove the plug from the outlet once the fan has stopped running.
9. Manual restart maybe required if power to this unit is interrupted.
10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening, as this may cause an electric shock or fire, or damage the heater.
11. To prevent a possible fire, do not block, or place anything in the front or rear of the heater.
12. When performing filter maintenance, do not force the filter to dry using alternative methods. Doing so could damage the filter.
13. A heater has hot and arcing or sparking parts inside. Do not use in areas where gasoline, paint, or flammable liquids are used or stored.
14. Insert the remote batteries in accordance with instructions. Incorrect polarity may cause the battery to leak which can damage the remote control or injure the operator. Danger of explosion or fire if batteries are mistreated. Replace only with the same or specified type. Do not dispose of batteries in fire or leave in direct sunlight for a long period of time.
15. Use this heater only as described in the manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons and may void the warranty.
16. Do not plug the heater into any other cord-connected device such as a power strip, surge protector, multiple outlet adapter, grounding adapter or outlet-type air fresheners. **Plug into a 3-prong 120v 15amp or higher grounded circuit receptacle only.** Do not plug the heater into a loose-fitting or broken receptacle. This heater is for use on 120 volt outlets. The cord has a plug as shown at "A" in the Figure below.



Product Setup

1. Unpackage heater. We recommend keeping the packaging for off-season storage and any transporting needs.
2. Find a level and unobstructed location to place the unpackaged heater.
3. Plug the power cord directly into an unused grounded 110 volt 15 amp or higher circuit receptacle.
4. Some models only: Make sure the POWER SUPPLY button, on the back of the unit, is in the ON position (I).
5. Press the **POWER** button in the control panel to turn on the heater.
6. Use the **WARMER** and **COOLER** buttons to adjust the heater thermostat.
7. To turn the heater off, press the **POWER** button; the fan will continue to run until all of the heat has been expelled.
8. Install two new AAA batteries in the remote control. Certain functions cannot be performed with the remote i.e., using the **TIMER** function or changing the temperature scale from Fahrenheit to Celsius.

Comfort Buddy Functions



Display Setting: The Comfort **BUDDY** is equipped with multiple temperature scales, i.e. Fahrenheit and Celsius. To change between these scales, press and hold the **QUIET** button until the display flashes. Pressing the **TIMER** button will cycle through the scales. Stop pressing the **TIMER** button once your preference scale is displayed. The display will stop flashing in a few moments. You can continue normal operation of the heater after the display stops flashing.

Quiet/Low Function: Press the **QUIET** button when you wish to run the heater at a lower wattage in order to use less electricity. Running the heater in quiet mode can sometimes be more beneficial in smaller rooms where less heat is necessary. The heater will also operate more quietly in this mode.

Auto ON Timer: With the heater **OFF**, press the **TIMER** button to select the number of hours you want the heater to wait until it powers on. You can select between 1-12 hours. Heater will power on at the last heat setting it was operated at.

Auto OFF Timer: With the heater **ON**, press the **TIMER** button to select the number of hours you want the heater to operate before it turns off. You can select between 1-12 hours.

To disengage the timer feature, simply press the **POWER** button or press the **TIMER** button until the timer is no longer indicated on the display.

Air Purification Function (Upgrade Kit Sold Separately): The Comfort **BUDDY** can easily be upgraded to include air purification technology. Follow the instructions included with the kit to install it inside the heater. For more information, please visit www.comfortbuddy.com.

IMPORTANT NOTE: If the **PURIFIER** button is pushed **WITHOUT** the optional upgrade kit, the message “Replace UV Bulb” will be displayed on the control panel. This message will remain until the **PURIFIER** button is pushed again. Also, with the purifier mode on, the fan will operate continuously.

Product Maintenance

The Comfort BUDDY heater comes equipped with an easy access washable lifetime filter.

IMPORTANT INFORMATION: If you have allergies and/or are sensitive to dust, you will want to use this filter. When choosing to use the filter, it must be cleaned on a regular basis; a clogged filter will cause the heater to not work to its full capacity.

To Clean the Filter:

1. Unscrew the knob screw of the filter to release the filter cover and pull it straight out.
2. Run warm tap water over the filter, the opposite direction of air flow, until water runs clear. The filter might excrete some filtered residue, so be cautious not to drip on any stainable surfaces such as carpeting. You can also soak the filter in water mixed with a small amount of mild dish soap (don't forget to rinse with water after soaking filter).
3. Shake the filter over a sink until excess water is removed and allow it to drip dry completely before reinstalling. DO NOT force the filter to dry using any alternative methods.
4. Reinstall the filter to the rear of the unit by positioning the filter back in place.
5. If using the optional HEPA filter that comes with the Air Purification Upgrade Kit, it can be cleaned by removing all dust and dirt with a vacuum attachment. Do not get the HEPA filter wet.



Resetting the “Clean Filter”

Notification:

A “Clean Filter” notification will be displayed on the control panel after 720 hours of operation. To reset the notification, press and hold the **PURIFIER** button for 5 seconds.

Cabinet Care:

Wipe clean with a soft damp cloth.

Heater Storage (long term):

1. Unplug the heater.
2. Wind up electrical cord so as to keep it off of the ground.
3. Cover the heater to prevent dust from accumulating on filter or internally.
4. Store the heater in a dry, low dust environment.

For maximum performance, please follow recommendations below:

1. For best results, do not locate the heater in an area with a high rate of air movement, as the warm air may be removed from the area you are intending to heat.
2. Try placing the heater near a warmer inside wall and direct the output toward a cooler outside wall. The cooler outside wall will tend to draw the heat toward itself, which will encourage more efficient heating.
3. Do not place the heater next to a cold air return, as this will draw the heat away from the area to be heated and prevent efficient heating. Experiment with the placement of the heater to see what works best for you.
4. To ensure maximum efficiency, a 40% (minimum) relative humidity should be maintained in the heated environment.
5. The heaters are designed to operate for maximum efficiency in a room temperature range from 40° to 90° F.
6. Try lowering your central heating system to a lower temperature and placing the heater in the area you spend the majority of your time. Now set the heater to your desired comfort level. After all, there is no point in heating multiple rooms when they are not in use.
7. When heating larger areas, place the heater in a central location. If a ceiling fan is nearby, try using it at the same time to help distribute the heat evenly.

Troubleshooting

PROBLEM

SOLUTION

Heater continues to run after I turn it off.

Wait! This is part of the normal cooling down process. Do not unplug unit while running.

Heater turns itself on and off.

Using its thermostat, this heater will turn itself off and on in order to maintain the temperature you have selected.

The air-flow seems diminished.

Most issues, including air-flow, can be resolved by cleaning the filter. Check manual for details.

When I turned the heater on, it started emitting a strange smell.

When the unit heats up, some users may notice a smell for the first few minutes. This smell is the result of various internal components coming into contact with elevated heat levels for the first time. The smell will dissipate after the unit runs for a few minutes.

The heater doesn't seem to produce as much heat as it once did.

First, try cleaning the filter (check manual for details). If cleaning the filter does not solve the problem, please call Customer Service at 1-888-281-9031 or visit www.airmore.com.

The heater tripped a circuit breaker in my home.

The heater is an appliance. It's never recommended to run more than one appliance on the same circuit. Make sure the heater is plugged into a grounded, 3-prong outlet and that it does not share a circuit breaker with any other appliances.

The heater has stopped working and it will not come back on.

The heater is equipped with a safety feature that keeps it from getting too hot. If the heater will not turn back on, it could be because that safety feature was activated. Shut the power off, unplug the unit and let it cool down for approximately 30-45 minutes. Take this time to clean your filter. After the unit has cooled down, try plugging it in and turning it back on. If this does not solve the problem, please call Customer Service at 1-888-281-9031.

I plugged the unit in and pressed the power button on the front of the unit but the unit did not begin heating.

First, make sure the switch on the back of the unit is in the on (1) position. Second, you may need to raise the selected temperature to get the unit to come on. If neither of these solve the problem, please call Customer Service at 1-888-281-9031.

Replace UV Bulb is displayed on the control panel

Please refer the "Air Purification Function" section under the "COMFORT BUDDY FUNCTIONS" section of this manual.

Clean Filter is displayed on the control panel

Please refer the "Resetting the "Clean Filter" Notification" section under the "PRODUCT MAINTENANCE" section of this manual.

Frequently Asked Questions

QUESTION

ANSWER

How do I get the filter off?

See “To Clean the Filter” section of this manual.

Where do I find the serial number?

On the back of the heater is a label with model number and serial number.

What does the red light that comes on when I plug the unit in mean?

The light simply indicates that the unit is plugged in, the master power switch is in the on position and that it can be turned on for use at any time.

Can I move the heater around while it's running?

No. It is not recommended to move any portable heater when it is operating. We recommended moving the heater only after it has been powered off and the fan has completely stopped.

What is the life expectancy of the PTC heating element?

The average life span of a PTC heating element is up to 80,000 hours. To replace a heating element, please call Customer Service at 1-888-281-9031 or visit www.airnmore.com.

Can I use the heater and other appliances at the same time?

Yes, as long as they are not running off of the same circuit. Zone heaters are considered an appliance and you should never run more than one appliance on a single circuit breaker. Your freezer, refrigerator, microwave, washing machine, dryer, heaters and other such appliances should not share a circuit breaker.

2 Year Limited Warranty

LIMITED WARRANTY

WARRANTY: The company warrants this product, to the original purchaser or gift recipient, to be free from defects in workmanship and materials, under normal use and service, for a period of two years from the date of purchase.

REFURBISHED HEATERS: All refurbished heaters have a 1-Year Warranty.

Warranty will be null and void if any of the following occur: The mechanics of the heater and/or the electrical cord and plug have been altered or tampered with in any way. Heater is not used correctly or not maintained according to the care instructions.

2 Year Limited Warranty (continued)

LIMITATIONS: ALL WARRANTIES IMPLIED BY LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THE LIMITED WARRANTIES SET FORTH ABOVE.

Some jurisdictions do not allow limitations on the length of the implied warranty, so the above limitation may not apply to you. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSS OF PROFIT OR MEDICAL EXPENSES CAUSED BY ANY DEFECT, FAILURE, MISUSE, OR MALFUNCTION OF THE PRODUCT.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The Company will not be responsible for damages or losses, direct or indirect, caused by misuse, abuse, accident, negligence, conditions of transportation or storage, or failure to follow instructions. The Company will not be responsible for any statements that are made or published, written or oral, that are inconsistent with this written warranty, or which are misleading or inconsistent with the facts as published in the literature or specifications by the Company.

In the unlikely event that your unit does not appear to be working properly, please have your proof of purchase handy and contact Customer Service at 1-888-281-9031. Prior to your call, we encourage you to visit www.COMFORTBUDDY.com for numerous troubleshooting tips and possible service instructions (if needed).

You can also e-mail us at info@airnmore.com.

SAVE THESE INSTRUCTIONS

Warranty Registration

Please return this card within 30 days of purchase to activate your warranty. Thank you.

Email Address _____

First Name _____ M.I. _____ Last Name _____

Street _____ Apt # _____

City _____ State _____ Zip _____

Model Purchased _____

Serial Number _____

Date of Purchase _____



Quality and Reliable Customer Service

We work hard to answer customer questions right away. Let us know how we can help.

HOURS OF OPERATION

Monday – Friday: 9:00am to 6:00pm EST

Saturday: 10:00am - 4:00pm EST

PARTS & SPECIAL ORDERS

As an authorized sales, service and parts dealer, we carry all parts for each product we sell. To ensure you receive the right part for your clean air, heating or cleaning product give us a call. We'll be glad to help you.

You can also visit our Part Finder page, which will guide you on what replacement parts are compatible with your heater.

CONTACT INFORMATION

Toll Free: 888-281-9031

Local: 845-520-3002

Email: info@airnmore.com

Better Living with Air & More

PO Box 585

Stormville, NY 12582

Better Living with Air & More
PO BOX 585
Stormville, NY 12582